


Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

09 20 24 031





Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

09 20 24 031



Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

09 20 24 031



Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

09 20 24 031



Zugknopf Ø 24 x 18 mm - Messing (23kt Gold)

09 20 24 031

Ersatzteilstückliste