


Seifenschale Ø 120 x 20 mm - Chrom

08 17 97 570





Seifenschale Ø 120 x 20 mm - Chrom

08 17 97 570



Seifenschale Ø 120 x 20 mm - Chrom

08 17 97 570



Seifenschale Ø 120 x 20 mm - Chrom

08 17 97 570



Seifenschale Ø 120 x 20 mm - Chrom

08 17 97 570

Ersatzteilstückliste