






Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
 Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA, GN, ...

A 7382 ..	
Pos.	Part No.
1	A 963 131 NU
2	A 963 132 NU
3	A 963 146 NU
4	A 960 890 NU
5	A 960 891 NU
6	A 960 706 NU
8	A 960 500 NU
9	A 861 441 XX
11	A 860 897 NU
12	A 861 447 XX
14	A 861 448 XX
15	A 960 704 NU
	A 962 476 NU
16	A 6677 XX

A 7383 ..	
Pos.	Part No.
1	A 963 131 NU
2	A 963 132 NU
3	A 963 146 NU
4	A 960 890 NU
5	A 960 891 NU
6	A 960 706 NU
7	A 963 443 NU
8	A 960 500 NU
9	A 861 441 XX
10	A 860 902 XX
11	A 860 897 NU
12	A 861 449 XX
13	A 860 901 XX
14	A 861 448 XX
15	A 960 704 NU
	A 962 476 NU
16	A 6677 XX




Ideal Standard


Joy

A 7382 .. A 7383 ..

0724 / A 868 624 R1



A7382







A7383







Ideal Standard International NV
 Corporate Village – Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

<https://www.idealstandard.com>





Pressure 0,3 MPa 3 bar	Temperature °C	Snowflake icon	0	1	2	3	4	5	6	7	8	9
			°C	°C	°C	°C	°C	°C	°C	°C	°C	°C
50°C	16°C		49,5	49,5	48	46	42,5	41	37	33,5	31	28
65°C	16°C		65	65	63,5	60,5	57	53,5	49	44,5	39	34,5
81°C	16°C		81	81	78,5	73	69	63,5	56	49	42,5	36



P	bar	MAX. 10	5	Q (3 bar)
0,5				
T	°C	MAX. 80	65	l/min
			40	23