








Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Rezervni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA, GN, ...

Pos.	Part No.	8	A 960 331 NU	15	A 962 530 NU
1	A 861 320 XX	9	A 963 181 NU	16	A 960 242 NU
2	B 960 862 XX	10	B 960 486 XX	17	A 962 041 NU
4	B 960 650 NU	11	B 960 167 XX	18	BE125 XG
5	A 861 181 NU	12	A 861 140 NU	19	A 861 098 XX
6	A 861 156 NU	13	N 960 006 NU		
7	F 960 985 NU	14	A 961 667 NU		





 max.
 8-10 Nm



Ideal Standard

Tonic II
 A 6347 ..

0322 / A 868 962
 Made in Germany



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com



